

SATRON®

LUMINA™ VC



INSTALLATION AND SETTING-UP INSTRUCTIONS MANUAL

TABLE OF CONTENTS

INTRODUCTION.....	3
VCT & VC Multichannel Transmitter	3
Process Measurement Techniques.....	3
INSTALLATION.....	3
Transmitter Installation.....	3
Mounting the Transmitter	4
VC Components.....	4
Electrical Connections.....	5
INITIAL SET-UP.....	7
Setting the Date and Time.....	7
Setting the Range for IO1.....	8
Setting the Range for IO2 (VCT).....	9
Setting the Range for IO2 (VC Multichannel).....	10
SAMPLE DATA COLLECTION.....	11
Sample Data Collection at the RDU.....	11
Sample Data Collection Using a Sampling Switch.....	11
DATA COLLECTION AND DATA RETRIEVAL.....	12
Consistency Calibration.....	12
Entering Laboratory Values to the Transmitter.....	12
Two-point Sampling Method for Calculating Offset and Gain	13
Sampling for VC Multichannel: An Advanced Calibration.....	13
CREATING THE .SIF – FILE.....	14
ENTERING CALIBRATION PARAMETERS MANUALLY INTO THE TRANSMITTER.....	15
Entering Consistency Calibration Parameters.....	15
Entering Consistency Calibration and Range Parameters with SILogAdvisor.....	16
Entering Lab Data and Calculating Consistency Parameters with SILogAdvisor.....	16
Calculating Consistency Parameters	17
Entering the Second Channel Calibration Values.....	17
ERROR WORDS.....	18



INTRODUCTION

VCT & VC MULTICHANNEL TRANSMITTER

The VCT family of transmitters utilize the latest LED based strobe techniques using multi-frequency light measurement. The VCT measures Consistency in the 0 to 12%CS range. The VC multichannel measures Consistency on channel one and one of the following measurements on channel two: Ash, Brightness, Freeness, Kappa, Fiber Length or Shives Content.

The Remote Display Unit (RDU) provides a local display of the measured values and serves also as a simple menu-driven calibration and troubleshooting interface.

The RDU includes two analog 4–20 mA outputs, 3 dry contact binary inputs and 3 contact outputs.

PROCESS MEASUREMENT TECHNIQUES

The VC family of transmitters measures process parameters by transmitting multichannel strobes of light into the pulp and measuring the back-scatter characteristics. These measurement values are calibrated by sampling and laboratory analysis of process and the measurement accuracy is determined by the accuracy of the laboratory analysis results.

Since the calibration is dependent on sampling and analysis, it is imperative that the sampling techniques described in the Calibration section are carefully followed.



INSTALLATION

TRANSMITTER INSTALLATION

For total consistency, VCT


The location of the transmitter should be on the high-pressure discharge of the pump in the turbulent flow. The optimal location is on a 45-degree angle off the centre line of the discharge.

For multichannel, VCx

The location of the transmitter should be in a laminar flow condition in a horizontal pipe section. Drill a 34 mm diameter hole at 15° angle into the pipe so that the nipple inserts through the pipe wall. After welding, ensure that nothing (welding slag) obstructs the insertion path through the pipe.

Attach the isolation ball valve to the coupling. Once this is complete and the valve closed, the process can be restarted.

Important: while the process is down, attach the ball valve and check that the transmitter will insert fully into the pipe and can be locked in the place with the locking nut.



MOUNTING THE TRANSMITTER


To mount the transmitter, ensure O-ring seal is between the screw fitting and ball valve. Insert the screw fitting on the end of the transmitter into the ball valve and tighten the screw fitting (a).

Open the ball valve and push the transmitter through the valve and lock in place with the locking nut (b). In some cases, under higher pressure applications, the insertion tool may be required.

Insertion and removal tool is optional and is not included with the purchase of the transmitter (code: M1050140).


To remove the transmitter, reverse the above steps.

Warning: When removing the transmitter, do not loosen screw fitting (a) unless the ball valve is closed!



VC COMPONENTS

The figures below show a combination of many of the components of the VC family. An order will contain a combination of these components along with any additional components associated with special orders.





VC transmitter + ball valve + coupling




Connection cable for RDU (15m)





Remote Display Unit (RDU)



Connection box (K)



Insertion and removal tool



ELECTRICAL CONNECTIONS


Supply voltage to the transmitter is 24 Vdc and requires up to 200 mA current. It is recommended that a shielded twisted-pair cable is used as a signal cable. The signal cable should not be installed near high-voltage cables, large motors or frequency converters.

The shield of the cable should be grounded at the end of the power supply or in accordance with the recommendations of the manufacturer of the control system used and the regional electrical code. At the RDU end there's a dedicated screw for connecting the cable shield (1).

The Satron VCT transmitter remote display unit (RDU) can be provided with a wall box which can have a 10/15 meters cable between the transmitter and the sensor unit. Inside the RDU, there is a terminal for up to 3 binary Inputs (DI1, DI2, DI3). 3 relay outputs (DO1, DO2, DO3) and 2 analog 4–20 mA output signals (IO1, IO2).

The wiring connections to the RDU are shown below.



- ⚠ Do not connect or disconnect signal cable of the RDU while the device is powered up.**
- ⚠ Do not connect older generation M1/M2 sensors or RDU to new M3 generation devices.**




Protection fuse function selection:
 LATCH-OFF after the fuse has triggered, device will be kept off until Restart is pressed
 AUTO-RETRY device will try to automatically reset the fuse after it has been triggered
 COMM Hart® communication terminals
 LOOP1 mA loop 1 test terminals
 LOOP2 mA loop 2 test terminals

First mA loop (IO1) connection with external power supply, isolated mA loop. Preferred mode.


First mA loop (IO1) connection (3-wire), non isolated mA loop.




Second mA loop (IO2) loop connection (2-wire)




Digital input



Digital output



Device enclosure (K) connection to PLC



INITIAL SET-UP

Ensure that the sensor's electrical connections are correct and the cable is securely connected to the RDU. Otherwise, the following error screen will appear.



The RDU can display live operating conditions, perform diagnostic tests, view device information and set configuration parameters for proper operation. The Satron RDU is the local interface and consists of operating keys:

- Press **ESC** to go the main menu, move back towards the top of the main menu or to cancel the current action.
- Press **ENTER** to move to a lower menu level, to accept a configuration/command or enter a setting or parameter value into the transmitter memory.
- Use the **LEFT** [**←**] arrow key to move left on the current menu level.
- Use the **RIGHT** [**→**] arrow key to move right on the current menu level.
- Use the **UP** [**↑**] arrow to increase a parameter value.
- Use the **DOWN** [**↓**] arrow to decrease a parameter value.
- Press **SAM** to take a sample.
- Function button 1, **F1**
- Function button 2, **F2**

The main menu has 5 submenus: Configuration, New Sample, Calibration, Diagnostics, and Advanced. When the transmitter is powered up it will show the main display, i.e. Process Value.

The initial set-up consists of three steps.

1. Set the Date and Time
2. Set the operating range for Consistency (IO1).
3. Depending on the need and transmitter type, set the operating range for IO2.

SETTING THE DATE AND TIME

It is very important to set the correct date and time in the transmitter. The date and time are used to time stamp the samples extracted from the process and to mark the diagnostic events that may occur during transmitter operation.

The time and date values are set through the Configuration Menu/System Configuration Submenu.

1.06 %CS

Starting at the default PV display value; Press the **ESC** button.

CONFIGUR

Press the **ENTER** button to enter the Configuration sub-menu.

SYSTCONF

Use the **LEFT/RIGHT** arrows to move within the Configuration sub-menus.

RTC

When the System Configuration sub-menu appears in the display, press the **ENTER** button.

SET

When the RTC sub-menu appears in the display, press the **ENTER** button.

01012024

When the Set menu item appears in the display, press the **ENTER** button.

The date sub-menu will appear first and is in the format of **DDMMYYYY**.

Use the **UP/DOWN** arrows to set the day. then press **RIGHT** to move to the month. Use the **UP/DOWN** arrows to set the month, then press **RIGHT** to move to the year. Use the **UP/DOWN** arrows to set the year. Press **ENTER** to move to the Time.

00-00-00

The time sub-menu will appear in the format **HH-MM-SS**. Use the **UP/DOWN** arrows to set the hour, then press **RIGHT** to move to the minutes.

Use the **UP/DOWN** arrows to set the minutes, then press **RIGHT** to move to the seconds.

Use the **UP/DOWN** arrows to set the seconds if desired and press **ENTER** or simply press **ENTER** to accept the seconds as they appear.

RTC

The RTC sub-menu will appear in the display. Press the **ESC** button until the PV reading in the main menu is displayed.

1.06 %CS

SETTING THE RANGE FOR IO1

By default, the factory setting for the range is 4 mA = 0%CS and 20 mA = 7%Cs. However, this is configurable to match the operating range of the specific application for this example, the range will be changed to 2%CS to 4%CS.

1.06 %CS	Starting at the default PV display value; Press the ESC button	7.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.
CONFIGUR	Press the ENTER button to enter the Configuration sub-menu. Use the LEFT/RIGHT arrows to move within the Configuration sub-menus	4.0000000	
MAOUTPUT	When the MA Output sub-menu appears, press the ENTER key and "MA 1?" text will appear in the display.	SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.
MA 1 ?	Select MA 1 pressing ENTER key and lower range value (LRV) menu item will appear.	URV	Press the ESC button until the PV reading in the main menu is displayed.
LRV	Press the ENTER button to display the current LRV .	1.06 %CS	
0.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.		
2.0000000			
SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.		
LRV	Use the RIGHT arrow to move to the upper range value (URV).		
URV	Press the ENTER button to display the current URV		

SETTING THE RANGE FOR IO2 (VCT)

1.06 %CS	Starting at the default PV display value; Press the ESC button	IO2 URV	Within I/O CONF menu use LEFT/RIGHT arrows to find IO2 upper range setting. When IO2 URV menu item appears, press ENTER .
CONFIGUR	Press the ENTER button to enter the Configuration sub-menu. Use the LEFT/RIGHT arrows to move within the Configuration sub-menus.	7.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.
I/O CONF	When the I/O CONF sub-menu appears, press the ENTER key to enter the submenu. Use the LEFT/RIGHT arrows to move within the I/O CONF sub-menu.	4.0000000	
IO2 SRC	When IO2 menu item appears, press ENTER key and IO2 source (IO2 SRC) menu item will appear, press ENTER .	SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.
MA	Use LEFT/RIGHT arrows to select source for IO2, when item MA appears, press ENTER to select.	IO2 URV	Press the ESC button until the PV reading in the main menu is displayed.
SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.	1.06 %CS	
IO2 LRV	Within I/O CONF menu use LEFT/RIGHT arrows to find IO2 lower range setting. When IO2 LRV menu item appears, press ENTER .		
0.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.		
2.0000000			
SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving. After pressing ENTER you will return to I/O CONF submenu.		

SETTING THE RANGE FOR IO2 (VC MULTICHANNEL)

1.06 %CS	Starting at the default PV display value; Press the ESC button	7.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.
CONFIGUR	Press the ENTER button to enter the Configuration sub-menu. Use the LEFT/RIGHT arrows to move within the Configuration sub-menu.	4.0000000	
MAOUTPUT	When the MA Output sub-menu appears, press the ENTER key and "MA 1 ?" text will appear in the display. Use the LEFT/RIGHT arrows to move within the MAOUTPUT sub-menu.	SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.
MA 2 ?	When MA 2 ? menu item appears, press ENTER key and lower range value (LRV) menu item will appear.	URV	Press the ESC button until the PV reading in the main menu is displayed.
LRV	Press the ENTER button to display the current LRV	1.06 %CS	
0.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.		
2.0000000			
SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.		
LRV	Use the RIGHT arrow to move to the upper range value (URV).		
URV	Press the ENTER button to display the current URV		

SAMPLE DATA COLLECTION

The key to a good regression analysis is the correct time correlation of the transmitter measurement values and the lab sample. To ensure an accurate time correlation, one of two procedures needs to be followed:

1. Sample data collection at the RDU
2. Sample data collection using a Sample Toggle Switch

SAMPLE DATA COLLECTION AT THE RDU

To ensure an accurate time correlation, use the following procedure using the Remote Display Unit (RDU):

1.06 %CS

Starting at the default PV display value; Press the **ESC** button

NEW SAMP

Use the **UP/DOWN** arrows to move to the New Sample sub-menu and press **ENTER**.

START ?

The **START?** appears in the display. When you are ready to collect the sample press the **ENTER** Key.

SAMPLING

The display will blink the Sampling message during the sampling period. Collect the sample as quickly as possible and after the sample is complete, press the **ENTER** key to save or **ESC** to cancel. The sample time stamp, average, min and max values will scroll across the display.

SAVE

Press the **ENTER** button to display the current **LRV**

OK

An **OK** message and the Sample Number will appear. Record the Sample number, time stamp and Average value as a reference. Internally the sample number is automatically incremented by the transmitter each time a new sample is saved.

NEW SAMP

The display will automatically return to the New Sample sub-menu. Press the **ESC** key until the PV reading in the main menu is displayed. After the lab testing is completed, record the lab data with the appropriate Sample Number and time stamp in an Excel spreadsheet.

1.06 %CS

Alternatively, directly press the sample (**Sam**) button in the RDU, the display will blink the Sampling message during the sampling period. Continue as previously instructed.



SAMPLE DATA COLLECTION USING A SAMPLING SWITCH (K BOX)

This is best performed by two people. When the sample person is ready to take a sample, the other person activates the switch by moving it to the sampling position. The Remote Display Unit (RDU) inside the enclosure will flash "**SAMPLING**". The person operating the sample valve then extracts the sample from the process into a container. After the sample has filled the container the switch person turns the switch immediately back to its original position trying to time the switch movement with the close of the sample valve. The RDU will display the sample number (**SAMPL 01**) and a message that the sample was "**OK**".

It is important to make the sampling time as short as possible because the transmitter is averaging all the readings while the switch is activated. After the sample is complete, mark with the date/time and the sample number that appears to the RDU window. Also mark the primary reason for the sample. For example, if the transmitter measures both consistency and kappa, note that sample 2 was for consistency and samples 3 through 6 are for kappa etc.

Consider setting up a spreadsheet for recording the lab values. The key is recording the correct time for the sample. When the sample data is extracted from the .sif file (see Creating a .sif File section) the samples numbers do not appear, therefore the date and time are used to correlate the lab data to the internally stored averages.

In some cases, the same sample may be used for consistency and a complex variable. Enter both lab values with the same time stamp in the Excel spreadsheet.

This spreadsheet along with the sif-file that is extracted from the transmitter should be sent to Satron for analysis. Satron will send back the calibration coefficients to insert into the VC multichannel for this application.

DATA COLLECTION AND DATA RETRIEVAL

The mill's standard for collecting consistency samples should be enough. The **TAPPI T 240** standard is a good reference.

Note: The sample extraction location should be located as close as possible to the transmitter for the best results. Normally located 0,5 meters downstream of the transmitter.

The first component to accurately calibrate the transmitter is to employ consistent sampling and laboratory techniques. It is valuable if the sampling can be scheduled so that the same person collects and tests the samples during the data gathering period (**consistency**). This minimizes sample variability.

The second component to successful data collection is the accurate time correlation between when the sample is taken, and the internal raw readings made by the transmitter. It is recommended that two people work together to collect the samples. One person is the sampler/tester that will physically collect the sample and the second person is at the **RDU** (or Sampling switch) to initiate the transmitter data collection period and time stamp the sampling and meter readings made while the sample is extracted.

CONSISTENCY CALIBRATION

There is a standard methods to perform a successful consistency calibration via RDU (which automatically store new consistency parameters to current recipe): Two-point sampling method for calculating offset and gain. Multi point calibration is possible with SiLogAdvisor consistency calibration simulator.

ENTERING LABORATORY VALUES TO THE TRANSMITTER

In order to utilize calibration functions in the transmitter, the corresponding laboratory values for samples need to be entered into the transmitter. Use the following procedure to enter the laboratory values:

1.06 %CS	Starting at the default PV display value; Press the ESC button	0.000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number. If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save.
CALIBRATION	Use the LEFT/RIGHT arrows to move to the Calibration sub-menu and press ENTER .	2.000000	
SAMPLES	Use the LEFT/RIGHT arrows to move to the Samples sub-menu and press ENTER .	OK	
SAMPL 01	Use the LEFT/RIGHT arrows to move to the corresponding sample and press ENTER .	SAMPL 01	An OK message will appear in and the display will automatically return to the Sample sub-menu. Press the ESC key until the PV reading in the main menu is displayed
LAB PV	The LAB PV will appear in the display. Press the ENTER key to enter the laboratory values for the consistency.	1.06 %CS	

TWO-POINT SAMPLING METHOD FOR CALCULATING OFFSET AND GAIN

Use the following procedure to calibrate the consistency measurement with two sample points (you can also use the water point stored in the transmitter as the first sample point):

1.06 %CS	Starting at the default PV display value; Press the ESC button	SAVE ?	When SAVE? appears in the display, press ENTER to accept or ESC to exit without saving.
CALIBRATION	Use the LEFT/RIGHT arrows to move to the Calibration sub-menu and press ENTER .	OK	An OK message will appear in and the display will automatically return to the Calibrate sub-menu.
CALIBRATE	Use the LEFT/RIGHT arrows to move to the Calibrate sub-menu and press ENTER .	CALIBRATE	
	Transmitter asks you to select first calibration data point, press ENTER . Use the LEFT/RIGHT arrows to move to the corresponding sample and press ENTER . You can also use the water point stored inside the transmitter as the first calibration point (SAMPH20)	CALIB HISTORY	Press RIGHT to Calib History and press ENTER to see Calibrations information with gain and offset.
SAMPL 01		0.99 %CS	Press the ESC key until the PV reading in the main menu is displayed.
SAMPH20			
OK	An OK message shortly appears in the display followed by the request to select next data point and next sample item will appear in the display. Use LEFT/RIGHT arrows to select second calibration point and press ENTER .		
SAMPL 02			

SAMPLING FOR VC MULTICHANNEL: AN ADVANCED CALIBRATION

Unlike consistency, the best calibration of the VC multichannel requires much more complex analysis and close coordination of transmitter information to the exact time that the sample is extracted from the process. There are two output channels in the VC multichannel, one for Consistency of the stock and the other for the specific parameter being measured. Kappa, Ash, Freeness, Brightness etc. must be carefully determined in the laboratory and the results correlated to the transmitters measured variables. The result is that the parameters measured and displayed on the second channel are non-linear in nature and the calibration is significantly more complex to accomplish. Therefore, more process analysis data is needed to complete these calibrations. It is recommended that twenty-five to thirty samples and lab analyses must be collected for the calibration purposes.

The same range of operation applies; the samples need to cover at least fifty percent of the operating range of the variable. The same two-person data collection procedure should be followed. The key to accurate results is to correctly record the date and time stamp when the sample is taken. The external sampling switch helps to improve the accuracy of the sampling and time stamping that is necessary for good results.

Once the data is collected, a multi-variable polynomial regression analysis is performed to determine the unique calibration curve for each application. The transmitter uses a linear equation in three variables as the calibration curve for the application.

CREATING THE .SIF – FILE

- The SILogAdvisor software provided by Satron Instruments is used to create the sif file (Satron Information File). This software is downloaded from the Satron website (Contact -> Support and Service) and installed on a laptop that can be connected to the USB-C port inside the transmitter cap (1) or the RDU (2). See the instructions in the Satron Operating Manual to locate, download and install this software. The manual also includes instructions for using all features of the software.

- Connect a USB-C cable (this cable is not provided with the transmitter) to the port under the transmitter cap (1), or the RDU (2) to an USB port on the laptop. The USB-C port on the sensor is faster than the one in the RDU.

- Start the SILogAdvisor application on the laptop.

- After the opening window appears, verify the port connection. If the Port window appears blank, click the DOWN arrow and select the COMx-port that is connected to the Satron transmitter. Click the CONNECT button in the Connection dialog.

- A connection will be established to the transmitter and the buttons in the Events & Data dialog box will become active.



- Select the All option button and click the Read button.

- The data will be downloaded from the transmitter to the SILogAdvisor. This may take some time. While data is being read, the File and Erase data buttons are deactivated and the Read button changes to Cancel. When the data download is complete, the File and Erase data buttons will become active again and the Read button will replace the Cancel button. This is the indication that the download is complete.

- Click the File button and select the "Save SI file (*.sif)". Give the file a name and select a location on the laptop to save the data.

- This file along with any other related data files (i.e. lab data results) are essential information for technical support of the VC product.

- After data extraction, remove the USB-C cable and reinstall the transmitter cap. Ensure that the cap is fully sealed.



ENTERING CALIBRATION PARAMETERS MANUALLY INTO THE TRANSMITTER

There are separate methods for entering tuning constants. Tuning **PV** for consistency (**IO1**) are entered using the **RDU**. Tuning for the second variable (**PV2**) is recommended to enter using the **SILogAdvisor** laptop Interface.

ENTERING CONSISTENCY CALIBRATION PARAMETERS

Once the gain and offset parameters are known, enter them into the transmitter at the **RDU** panel as shown below:

1.06 %CS	Starting at the default PV display value; Press the ESC button	SAVE ?	Press ENTER to save the value or ESC to cancel out of the operation. The OFFSET sub-menu item will reappear.
CALIBRATION	Use the LEFT/RIGHT arrows to move to the Calibration sub-menu and press ENTER and the RECIPE sub-menu Will appear.	OFFSET	Press the RIGHT arrow to move down the menu to the GAIN sub-menu and press ENTER to enter the GAIN sub-menu.
RECIPE	Press ENTER to enter the sub-menu	GAIN	
MA 1 ?	The MA 1 ? menu item will appear Press ENTER and the OFFSET sub-menu will appear.	0.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . Note: the first digit on the left can be set to a (-) sign so remember to account for this when entering the decimal. A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save. The SAVE? item will appear.
OFFSET	Press ENTER to enter the OFFSET sub-menu	2.0000000	
0.0000000	Use the LEFT/RIGHT arrows to place the decimal point in the proper location and press ENTER . Note: the first digit on the left can be set to a (-) sign so remember to account for this when entering the decimal. A cursor will appear to indicate the digit that will be modified. Use the UP/DOWN arrows to change the number If more change is needed, move RIGHT and the cursor will move to the right position. Press ENTER to save. The SAVE? item will appear.	SAVE ?	Press ENTER to save the value or Esc to cancel out of the operation. The GAIN sub-menu Item will reappear.
2.0000000		GAIN	Press the ESC key until the PV reading in the main menu is displayed.
		1.06 %CS	

ENTERING CONSISTENCY CALIBRATION AND RANGE PARAMETERS WITH SILOGADVISOR

It is also possible to enter the consistency tuning parameter to the transmitter using the SILogAdvisor software.


First attach the laptop to the transmitter, start the **SILogAdvisor** software and connect as directed previously.

Click the File – drop down button and select “**VC Consistency calibration simulation**” from the menu.

On the device section of the **VC Consistency calibration simulation** window, you can select recipe to edited from drop down menu (1) and retrieve the current gain and offset values from the transmitter by clicking the Read button (2). Values for the gain and offset together with URV and LRV values can be typed into the corresponding input windows (3). Values will be stored into the transmitter by clicking the “Write” button (4).

A write warning will appear and simply click “Yes”.

After the operation is complete, a successful write message will appear. Click “OK”.



ENTERING LAB DATA AND CALCULATING CONSISTENCY PARAMETERS WITH SILOGADVISOR


First attach the laptop to the transmitter, start the **SILogAdvisor** software and connect as directed previously.

Read event data from the transmitter as described in the chapter “**Creating the .sif – File**”. You may skip this step if you have only few sample points in the transmitter: 10 latest samples are stored in the **EEPROM** memory of transmitter, and those are automatically retrieved on the next step.

Enter “**VC Consistency calibration simulation**” window from “File” drop down menu (see previous chapter).


Entering Lab Data

To enter laboratory value, click first column (Runtime) (1) on the sample line you want to edit. Information of the sample will appear on the “Sample” section of the window (2). Type in the laboratory value into the “Lab” input window (3) and press “Set Lab” button (4). If the selected sample is in the **EEPROM** memory of the transmitter, software will automatically ask if you want to store the value to the transmitter. If you click “Yes”, lab value will be stored into the transmitter and pressing “No” will use the value only in the **SILogAdvisor** software. If the sample is in the Event memory of the transmitter, lab value is only used in the software and storing it into the transmitter is not possible.



CALCULATING CONSISTENCY PARAMETERS

After the lab value is set for a sample, it can be active as a sample to be used to calculate consistency parameters by clicking **"Enable"** button (5). With same button you can also remove sample from calculation (text on the button will change to **"Disable"** when sample is enabled). On the graph (6) you can see all the samples which have lab value: green ones are enabled for the calculation and black ones disabled. The blue line is the line defined by the current consistency parameters on the selected recipe and line is the fitted line for the selected sample points. Corresponding consistency parameters (Offset and Gain) are visible on the "Simulation" section of the window (7). If you want to store these values to transmitter, press **"Copy"** button (8), check that correct recipe is selected and click **"Write"** button (9). A write warning will appear and simply click **"Yes"**.



ENTERING THE SECOND CHANNEL CALIBRATION VALUES

The calibration constants for the second channel form a linear equation in three variables. Rather than entering the constants individually at the RDU, they can be entered all at once using the **SILogAdvisor** software.

Attach the laptop to the transmitter and connect as directed previously.

Click the **"File"** drop down button and select **"VC Regression Simulation"** at the bottom of the menu.



The VC Regression simulation window will open. There are three channels for entering parameters. PV is for channel one (IO1). Note: it is only active when channel one has been configured as a second variable. When IO1 is consistency, these parameters should not be changed - the gain and offset must be entered from the RDU or using **SILogAdvisor** as described in previous chapter.

PV2 is channel two (IO2) and **FTV3** is reserved for a future channel and is presently inactive. Also, in **PV** and **PV2**, the variables with a "D" in the name are associated with the future capability and are currently inactive.

The constants are typed into the windows associated with **FuN2** (intercept) and the three measurement components (**FuAM2**, **FuBM2** and **FuCM2**) (1). Once the values are entered in the input windows, click the **"Write"** button (2) above the **PV2** column and select the recipe where store coefficients. A write warning will appear and simply click **"Yes"**.

After the operation is complete, a successful write message will appear. Click **"OK"**.

If you wish to verify that the values were written, click the **"Disconnect"** button and then reconnect to the transmitter, reopen the **VC regression simulation** window click on the **"Read"** button (3) above the **PV2** column and the values stored in the transmitter will be displayed in the window.

ERROR WORDS

The content of error words 1...12.

EW number	EW bit	EW name (function)	Description
01	00	EW1	Turbidity / Consistency error (TU ER/CS ER)
"	01	"	Sensor temperature error (ST ER)
"	02	"	Electronics temperature error (ET ER)
"	03	"	Output under -10 % or over 110 % (RANGE ER)
"	04	"	Output current saturated (OUTSA WA)
"	05	"	ADC runtime error (ADCR ER)
"	08	"	ADC startup error (ADCS ER)
"	09	"	EEPROM read error (EERPR ER)
"	10	"	EEPROM write error (EEPRW ER)
"	11	"	EEPROM calibration error (EECAL ER)
"	12	"	HART error (HART ER)
"	13	"	System error (INTRN ER)
02	02	EW2	Overfeed timer (OFTMR ER)
"	04	"	ADCA error
"	05	"	ADCB error
"	06	"	DACA error
"	07	"	DACB error
"	08	"	DISP error
"	09	"	EEPR error
"	10	"	HARA error
"	11	"	HARB error
"	12	"	SYSA error
"	13	"	SYSB error
03	00	ADCA (A/D, LEDs)	ADC not found
"	01	"	Comm error
"	02	"	Invalid channel
"	03	"	Irpt timeout
"	04	"	Gain comm error
"	08	"	AINM undervoltage
"	09	"	AINM overvoltage
"	10	"	AINP undervoltage
"	11	"	AINP overvoltage
"	12	"	ADC saturation
"	13	"	ADC conversion error
"	14	"	Miscellaneous error
04	08	ADCB (")	LED comm1 error
"	09	"	LED comm2 error
"	10	"	LED short error
"	11	"	LED open error
05	00	DACA (D/A, I/O)	IOOUT not connected
"	01	"	Comm timeout
"	02	"	Frame error
"	04	"	VLoop 12V
"	05	"	VLoop 6V
"	06	"	Temp 100C
"	07	"	Temp 140C
"	08	"	ILoop under
"	09	"	ILoop over

"	12	"	Loop error
"	13	"	I/O comm error
06	00	DACB (")	IOUT2 not connected
"	01	"	I2 Comm timeout
"	02	"	I2 Frame error
"	04	"	I2 VLoop 12V
"	05	"	I2 VLoop 6V
"	06	"	I2 Temp 100C
"	07	"	I2 Temp 140C
"	08	"	I2 ILoop under
"	09	"	I2 ILoop over
"	12	"	I2 Loop error
"	13	"	I/O comm2 error
07	00	DISP (Display, RDU)	Keyb error
"	01	"	Disp error
"	08	"	No reply
"	09	"	Frame error
"	10	"	Checksum error
"	12	"	Keyb error (R)
"	13	"	Timeout error (R)
"	14	"	Frame error (R)
"	15	"	Checksum error (R)
08	00	EEPR (EEPROM, Flash)	Checksum error
"	01	"	Calibration error
"	08	"	CPU r/w error
"	09	"	Log r/w error
"	10	"	ADC r/w error
"	11	"	I/O r/w error
"	12	"	CON r/w error (R)
09	00	HARA (HART, USB, IO-Link)	Preamble error
"	01	"	Frame error
"	02	"	Too few chars
"	03	"	Checksum error
"	08	"	Timeout error (IOL)
"	09	"	Overflow error (IOL)
"	10	"	Checksum error (IOL)
10	00	HARB (")	RC2 Invalid selection
"	01	"	RC3 Passed parameter too large
"	02	"	RC4 Passed parameter too small
"	03	"	RC5 Too few data bytes received
"	04	"	RC6 Device specific command error
"	05	"	RC7 In write protect mode
"	06	"	RC16 Access restricted
"	07	"	RC18 Invalid units code
"	08	"	RC32 Device is busy
"	09	"	RC64 Command not implemented
"	10	"	RCxx Other single definition response code
"	11	"	RCxx Command-specific response code
11	00	SYSA (System)	WD reset
"	01	"	Invalid reset
"	02	"	Stack error
"	03	"	Hard fault

"	07	"	Fuse blow error
"	08	"	AVDD error
"	09	"	IOVDD error
"	10	"	ALDO error
"	11	"	DLDO error
"	12	"	20mV error
"	14	"	V6V error
"	15	"	V24V error
12	00	SYSB (")	WD reset (R)
"	01	"	Invalid reset (R)
"	02	"	Stack error (R)
"	03	"	Hard fault (R)
"	08	"	V24V error (R)
"	09	"	Vana error (R)
"	10	"	Vdig error (R)
"	11	"	I error (R)
"	12	"	Fuse blow error (R)
"	13	"	Vcc error (R,IOL)
"	14	"	Vdd error (R,IOL)

The background of the page features a large, light blue, stylized letter 'A' that spans most of the page. The 'A' is composed of two main diagonal strokes and a horizontal base. The Satron logo is centered over the upper part of this 'A'.

Satron®

Look Closer